



PART NUMBER: **T1164RL**

PRODUCT: **Steps**


APPLICATION: **10-13 SR5**
10-19 Limited

PARTS INCLUDED:	QTY
Driver Side Step	1
Passenger Side Step	1
HARDWARE PACK:	1
M8X30mm HC Bolt	12
M8 Flat Washer	12
M8 Lock Washer	12





Installation:


Step 1: Starting with the driver side, remove all factory side molding hardware and discard. **(Fig. A)**



Step 2: Starting with the Driver side step, **(Fig.B)** align brackets with the factory mounts. **Note:** The step brackets will slide under the side molding brackets. **(Fig. C)**



Step 3: Using the supplied 8mm x 30mm hex bolts, lock washer and flat washers, start into factory mount locations and loosely tighten. **NOTE:** *The front bracket will take one bolt through the lower factory bracket and step bracket and one through the upper factory brackets original location. (Fig. D)*



Step 4: After final positioning, torque each bolt location using a 13mm socket.

Step 5: Repeat steps 1-3 with Passenger side. This concludes the installation.

